






1




2




3




4




5




6



7




8




PUB1777-001




9




10




11



12



13



14



↓
<https://support.lexmark.com/>